

Model: SKH036

WASHING SINK



Descriptions:

- Material: Stainless Steel SUS304
- Sink Part Stainless Steel Sheet Thickness: 1.20mm
- Other Part Stainless Steel Sheet Thickness: 1.0mm
- Dimension: 1600mm(L)x630mm(W)x1100mm(H)
- Water Flux: 1200L/Hour
- Automatic Hand Sensor Water Supplying Controlling Mode;
- Automatic Sensor Controlling Liquid Soap Dispenser;
- Built-in Leakage Protecting Device;
- Automatic Temperature Controlling Water Mixer;
- Package: Plywood Wood Box

PRODUCTS SHOW



Put the hand close to the sensor, water will automatically flow, second time put the hand, water will automatically stop. If the users do not stop the water by sensor, the faucet will be automatically stopped by preset program in about 5 minutes



Note: Wall mounting type dispenser

Put the hand below the dispenser, liquid will automatically supply

4 steps may be presetted(0.5ml-2ml)

The liquid storage is 600ml

May use a.c power, avoid the trouble of replacing battery

Thermostatical electric water heater

